



INSTALL ADAPTER BRACKET KIT ASSEMBLY & BRACKET INSTALLATION GUIDE

INCLUDED:







WALL SURFACE MOUNTING

Note that the **BRACKET ASSEMBLY** consists of an **ARRAY BRACKET** and a **WALL BRACKET**.

1) **RUN WIRING** -- Run the wiring from the power amplifier to the location desired for mounting the JBL PRX ONE Array speaker system.

2) **ATTACH WALL BRACKET TO WALL** - Using a level to ensure that the **WALL BRACKET** is straight, secure the **WALL BRACKET** to the wall. Be sure to use the appropriate wall anchors for attaching the bracket. Use all four screw holes for maximum integrity and safety. Be sure that the slot feature is at the top.







3) ORIENTING TOP & BOTTOM ARRAY

This drawing shows the proper orientation of the two speaker modules, where the connection plate attaches and where the wall bracket attaches (onto the connection plate).

IMPORTANT: Note that the speaker will not work correctly if the TOP AND BOTTOM ARRAY are not oriented as shown.







4) CONNECT SPEAKER MODULES (Array) TOGETHER VIA CONNECTION PLATE

Attach *CONNECTION PLATE* to the *TOP AND BOTTOM ARRAY*, as shown together Attach *Array Bracket* to the 4 indicated threaded points on the *TOP AND BOTTOM ARRAY*'s rear cabinet, using the included M6-27L (6 mm diameter, 27 mm long) bolts, with lock and flat washers.







6) SLIDE ARRAY WITH ARRAY BRACKET ONTO WALL BRACKET

1 Once the wall mount has been attached to the wall and Array mount has been attached to the Array, loosely install the M6-L36 PIVOT BOLT (bolt, lock washer and flat washer on one side and flat washer, lock washer & nut on the other side) of the WALL BRACKET. Then slide the Array so that the ARRAY BRACKET engages into the WALL BRACKET, dropping the hook slot of the ARRAY BRACKET onto the PIVOT BOLT as shown in Drawing1.



2 Insert the top tilt-angle bolt through the appropriate hole – first insert screw suit A through the slot for continuous adjustment capability,then insert the screw suit B through one of the preset angle holes (see next page for more information about tilt angles). Install with M6-L36 bolt, lock washer and flat washer on one side and flat washer, lock washer & nut on the other side, as shown in Drawing 2. Make sure the bolt goes through holes in WALL BRACKET and in ARRAY BRACKET.

3 Final BRACKET ASSEMBLY is shown in Drawing 3.

TIGHTEN THE BOLTS.





7) MORE ABOUT TILT ANGLES -- The bracket allows for +/-15 degrees of up or down tilt. Because of the height of the speaker(2Arrays+1Adapter), make sure there are no bulges on the wall as the end of the speaker may hit them at any angle within the -15° to +15° area.

PRE- SET ANGLES and **CONTINUOUSLY VARIABLE ANGLE** -- The bracket has through holes for mounting angles of +/- 15 degrees in 5 degree increments. There is also a slot above the set of holes for continuously variable adjustment. The pre-set angles are recommended for accurate aiming in 5 degree increments and the slot for any angle between 5 degree increments. Either can be utilized for setting the speaker's tilt angle.



- 8) SET THE SWIVEL (PAN) ANGLE Loosen the top and bottom bolts on the pivot. Adjust the side-to-side swivel (ie, pan) aiming angle of the speaker. Tighten the bolts securely.
 Maximum Swivel Angles before Wall Interference The bracket swivels a full 90 degrees from side-to-side. However, when mounting the PRX ONE onto a wall, the side-to-side swivel is limited by the end of the speaker encountering the wall. The maximum swivel angle depends on the up/ down tilt angle setting.
- 9) SAFETY CABLE Attach a safety cable (not included) to any of the 6 mm inserts on the back of the PRX ONE - INSTALL ADAPTER BRACKET KIT cabinet using one of the extra included M6*L9 bolts or via an M6 forged shoulder steel eyebolt. Attach the other end of the cable to a secondary attachment point on the wall.





8) Install Adapter to Array

Insert Array adapter to the Bottom array. Once you hear a click, this indicates a secure installation







Final installation diagram

